



Renovation Tread Installation Instructions

HOW TO SELECT

The standard stairway will require a 9" deep renovation tread on each step and an 11" deep tread at the top of each run and at each intermediate landing.

HOW TO MEASURE

Determine the width of the existing step to be covered and deduct 6" to provide a 3" margin at each end.

STAIR PREPARATION

Badly worn or dished steps are re-leveled with a fast setting leveling compound. This will provide a level surface for installation of the renovation treads.

INSTALLATION

Renovation treads are furnished with 2 rows of drilled and countersunk holes. An application of construction adhesive to the underside perimeter of the tread as well as around each drilled hole will seal out water penetration.

On wooden steps, fasten renovation treads with wood screws. For attachment to metal steps fasten with bolts and nuts or self tapping screws. For masonry steps fasten with expansion shields and screws. Stainless steel fasteners are recommended for exterior steps.

- SAME INSTRUCTIONS FOR G4702 / SG4702
- 5" WIDE RENOVATION TREADS HAVE 1 ROW OF HOLES

American Safety Tread Co., Inc. makes no warranty of any kind, expressed or implied, except that the product furnished shall be of the standard quality of American Safety Tread Co., Inc. and the user assumes all risk and liability resulting from the use of the product whether used singly or in combination with other products. American Safety Tread Co., Inc. neither assumes nor authorizes any person to assume for American Safety Tread Co., Inc. any other liability in connection with the sale or use of the product sold, and there are no oral agreements or warranties collateral to or affecting this statement. The user shall make his own evaluation and tests to determine the suitability of the product for his purposes and American Safety Tread Co., Inc. makes no representations as to the use of this product. American Safety Tread Co., Inc. shall not, under any circumstances, be liable or responsible for any consequential, incidental, indirect or special damages resulting from the use of this product.